

# THE BIG BOXY MACHINE TOTE

12" x 20" Perfect size to carry the Singer 221/222 featherweight machine

## CUT OUT CHECKLIST

### EXTERIOR FABRICS:

### MONOGRAM/EMBROIDERY

Place 2.5" down, center on width

#### CUT: Front/Back

\_\_\_ 2 @ 12" wide x 19" tall

**OR: 2@10" tall x 12" wide (top) and 2@10" tall x 12" wide (bottom)**

\_\_\_ 1 @ 12" wide x 37 1/2" tall **FOAM**

#### CUT: Outer bag ends (different fabric?)

\_\_\_ 2 @ 10" wide x 15" tall

\_\_\_ 2 @ 10" tall x 15" **FOAM**

#### CUT: Front/Back Pockets (different fabric?)

\_\_\_ 2 @ 12 1/2" wide x 12" tall

\_\_\_ 2 @ 12 1/2" wide x 10" tall lining

\_\_\_ 2 @ 10" tall x 11 1/2" wide - **FOAM**

#### CUT: Outer bag end pockets (different fabric?)

\_\_\_ 2 @ 7" wide x 7" tall

\_\_\_ 2 @ 7" wide x 8" tall lining

\_\_\_ 2 @ 5 1/2" tall x 6" - **FOAM**

**Optional Wide Outer edge to edge pockets instead of 7"x7" inset end pockets:**

\_\_\_ 2 @ 10" wide x 8" tall

\_\_\_ 2 @ 10" wide x 9" tall - lining

\_\_\_ 2 @ 10" wide x 7" tall - **FOAM**

#### **Placement of small end pocket on outside:**

Find center of each end panel; find center of the pocket. Align the pocket bottom (right side down) with the bottom of the end panel, matching the center panel 1 3/4" up from the bottom. Stitch across, then flip the pocket right-side up and continue to sew along the two sides to make the pocket.

### INSIDE FABRICS:

#### CUT: Inside Front/Back

\_\_\_ 2 @ 12" wide x 18" tall

\_\_\_ 1 @ 12" wide x 35 1/2" wide - **FOAM**

**BOTTOM/OUTSIDE CREASE: 4 1/4" from each side of center seam**

#### CUT: Inside Bag Ends

\_\_\_ 2 @ 10" wide x 14" tall

\_\_\_ 2 @ 10" wide x 14" tall - **FOAM**

**Placement of Inside END pockets: 2" from bottom.**

#### **Optional Inside END pockets**

\_\_\_ 2 @ 10" wide x 12" tall \_\_\_ 2 @ 9" wide x 6" tall **FOAM**

#### **Optional Inside Front/Back Pockets-IS/FB POCKET**

\_\_\_ 2 @ 12" wide x 12" tall \_\_\_ 2 @ 11" wide x 6" tall - **FOAM**

**Placement: 12" from top.**

#### CUT: Handles 2 @ 60" x 1" web strapping

OR \_\_\_ 3 @ 3 1/2" X 42"

\_\_\_ Sub-cut ONE of these into 4 equal pieces \_\_\_ 2 @ 3 1/2" X 39" - **BATTING**

\_\_\_ ZIPPER: 26"

ZIPPER TABS: \_\_\_ CUT 2 @ 3 1/2" x 4" - FABRIC AND BATTING

\_\_\_ METAL FRAMES: 2 @ 18" with 3" bend at each end